

## **Manual implementation of NEW (as of 2007) Daylight Saving Time Schedule**

**Please note that manual implementation of Daylight Saving Time will require a manual adjustment on the second Sunday of March AND the first Sunday of November.**

### **Pensar 1000 / 2000 - Set Manual Daylight Saving Time**

1. Refer to your System 1000 Owner's Manual or download the latest version from <http://www.electrosem.com/system1000.pdf>.
- 1a. Refer to your System 2000 Owner's Manual or download the latest version from <http://www.electrosem.com/system2000.pdf>.
2. Follow the instructions on page 8, Installation Settings & Control, in order to enter setup mode.
3. Press the Mode Select button until "C.7" appears in the Mode window.
4. Press the Increase Adjustment button until "\_ \_" is displayed in the Data window.
5. Press the Mode Select button until " 1" or ".1" appears in the Mode window.
6. The unit is now configured to require manual changes for Daylight Saving Time .

### **Pensar 1000 - Change Hour Setting**

1. Follow the instructions on page 8, Installation Settings & Control, in order to enter setup mode.
2. Press the Mode Select button until "=1" appears in the Mode window.
3. Press the Increase/Decrease Adjustment button until the correct hour is displayed in the Data window.
4. Press the Mode Select button until " 1" or ".1" appears in the Mode window.

### **Pensar 2000 - Change Hour Setting**

1. Press the Mode Select button until " 6" or ".6" appears in the Mode window.
2. Follow the instructions on page 3, Locking, in order to change control data.
3. Press the Increase/Decrease Adjustment button until the correct hour is displayed in the Data window.
4. Data is automatically locked if no switches are pressed for more than two minutes.